

Tel (852) 2406 8223 fax (852) 2406 8211

www.roxychemical.com

WN-88 Screw Rod Detergent 螺桿清洗劑

Product Features 產品特點

WN-88 is thermal stable, without abrassive material. When changing different colour of different resin, please apply WN-88 inside the screw rod (Hopper) directly without any other additive or premix. Apply it with a low dosage each time that can effect and ideal cleaning performance.

WN-88 具熱安定性, 無磨損性. 在轉色時直接加入螺桿(料斗)使用, 毋須添加其他化學助劑或預先混合, 每次使用少量即可達至理想清洗效果.

Application 用途

- (1) Apply to the sleeve and screw rod of any plastic injection mould machine or extrusion mould machine.
- (2) During changing the plastic resin or exchanging different color.
- (3) Cleaning the sleeve and screw rod at the process of mantainance or exchanging different moulds.

- (1) 塑膠注塑機及押出機料管之清潔.
- (2) 更換原料或顏色時之清洗.
- (3) 例行停機或換模時清洗料管.

Application 使用步驟

- (1) Spray throughly to the plastic resin which can mould for 5 injection (4 oz machine)
- (2) Mix those plastic resin well.
- (3) Wait for 1 to 2 min. before injection in the hopper (repeat the above steps, but do not Inject the plastic resin continously).
- (4) After spray our all the treated plastic resin, clean the hopper well, and then prepare the normal injection.

- (1) 用清洗劑噴濕約 5 次注塑之塑料 (4 安機以下)
- (2) 用手套或膠袋混和
- (3) 儲料後等 1 至 2 分鐘, 才把塑料射出 (重覆以上程序, 勿連續射出)
- (5) 將料斗(Hopper)清潔乾淨, 加入轉色後所用新塑料, 將之前餘料射出後即可正常注塑